# Distal Elbow Set



INSTRUCTIONS FOR USE

**R**: For use by physicians only. Caution: Federal Law restricts this device to sale by or on the order of a physician.

## Failure to follow instructions may lead to patient injury.

This package insert is designed to provide Instructions for Use of the Distal Elbow Set; it is not a reference to surgical techniques. Prior to use of each system in the Distal Elbow Set, the surgeon should become familiar with all information contained in this pamphlet.

#### **Description:**

The Skeletal Dynamics Distal Elbow Set consists of the following systems:

- 1. Distal Elbow Plating System
  - a. Proximal Ulna Plating System
  - b. PROTEAN Elbow Plating System
- 2. REDUCT Headless Compression Screw System
- 3. ALIGN Radial Head System
- 4. Internal Joint Stabilizer- Elbow System



The ALIGN Radial Head with Lock Screw and Radial Stems are supplied sterile using gamma radiation sterilization.



All other components of the system are provided non-sterile to be sterilized in the user facility.

#### Distal Elbow Plating System

The Skeletal Dynamics Distal Elbow Plating System consists of titanium alloy plates and screws, cobalt chrome cannulated polyaxial locking screws, k-wires, and specialized instrumentation designed for fracture fixation, fusions, osteotomies and non-unions of the radius and ulna.

The Distal Elbow Plates are available in various configurations: PROTEAN Radial Head Plates (left and right), Coronoid Plates (left and right), Y, Double Hockey Stick, Extended PROTEAN Radial Head Plates (left and right), Proximal Ulna Plates (73mm, 108mm, 151mm, left and right), FreeFix Proximal Ulna Plates (74mm, 91mm, 107mm, 122mm, 139mm, 155mm, left and right) and Proximal Ulna Plate Extensions (1 and 2 hole). The titanium screws are available in locking and non-locking configurations. The cobalt chrome cannulated polyaxial locking screws are available in 2.5mm diameter for use with PROTEAN Plates and 3.0mm diameter for use with Proximal Ulna Plates.

Distal Elbow Plating System Indications for Use: The Skeletal Dynamics Distal Elbow Plating System is intended for fixation of fractures, fusions, osteotomies and non-unions of the radius and ulna, particularly in osteopenic bone.

#### **REDUCT Headless Compression Screw System**

The REDUCT Headless Compression Screw (HCS) System consists of 2.5mm and 3.5mm cannulated titanium screws and specialized instrumentation. The 2.5mm screw is available in 11 length configurations between 10mm - 30mm, with increments of 2mm. The 3.5mm screw is available in up to 11 length configurations between 10mm - 45mm, with increments of 2mm and 5mm after 30mm screw lengths.

REDUCT HCS Indications for Use: The Skeletal Dynamics HCS System is intended for fixation of osseous fragments or fractures, arthrodesis of small joints, and osteotomies, with the appropriately sized screw.

#### ALIGN Radial Head System

The ALIGN Radial Head System (RHS) is a radial head prosthesis and instrumentation platform that is designed to orient the Radial Head perpendicular to the axis of forearm rotation. The fluted titanium plasma coated Radial Stem is press fit into the medullary canal of the radius. Combined with its unique instrumentation, it offers the flexibility to adjust the orientation during implantation and restore motion at the Radial Head, then locks to form a monoblock prosthesis after the optimal implant positioning has been achieved. It is comprised of multiple sized CoCr Radial Heads with Lock Screw, multiple sized titanium alloy Stems with titanium plasma spray (TPS) coating, and system specific instrumentation.

ALIGN Radial Head Indications for Use: The ALIGN Radial Head System and instrumentation are designed specifically for replacement of the radial head for degenerative or post-traumatic disabilities presenting pain, crepitation, and decreased motion at the radio-humeral and/or proximal radio-ulnar joint with:

- Joint destruction and/or subluxation
- Resistance to conservative treatment
- Primary replacement after fracture of the radial head
- Symptomatic sequelae after radial head resection
- Revision following failed radial head arthroplasty
- The system is intended for press-fit use

#### Internal Joint Stabilizer- Elbow System

The Internal Joint Stabilizer- Elbow (IJS-E System) provides temporary subcutaneous stability between the distal humerus and proximal ulna in patients who have elbow instability allowing for early active mobilization and function of the elbow. The construct consists of a Base Plate, Distal Connecting Rod, and Proximal Connecting Rod, that are held together by adjustable locking joints and locking screws, allowing for multiple degrees of freedom. Designed for a universal application, the Base Plate can be secured to either the left or right ulna using 3.5mm Non-Locking Polyaxial Screws. The Proximal Connecting Rod is then secured to the distal humerus at the axis of rotation using the appropriate sized Axis Pin.

The instrumentation includes elbow Axis Guides in three sizes, various gauges and other system specific guides and drills which enables the surgeon to identify the axis of rotation of the distal humerus, and optimally position the device dependent of the patient's morphotype. The System is comprised of a universal titanium IJS-E construct, multiple sized CoCr humeral Axis Pins, Stainless Steel K-wires (Guide Wires) for optimal prosthesis alignment (not to be implanted), and system specific instrumentation.

Internal Joint Stabilizer- Elbow Indications for Use: The IJS-E System is intended to provide temporary stabilization of the elbow joint after trauma or chronic elbow dislocation.

#### **Contraindications:**

Prior to using the system, ensure that none of the following patient conditions are present: active or latent infection, sepsis, osteoporosis, insufficient quantity or quality of bone and/or soft tissue, material sensitivity (if sensitivity is suspected, tests are performed prior to implantation), or patients who are unwilling or incapable of following post operative care instructions. The system should not be used in pediatric patients or patients with open growth plates.

The REDUCT Headless Compression Screw System is not intended for screw attachment or fixation to the posterior elements (pedicles) of the cervical, thoracic, or lumbar spine.

The IJS-E System should not be used if there insufficient quantity or quality of bone (bone loss greater than 30% of the total articulation or involving an entire column of the distal humerus, or coronoid bone loss of 50% or more).

#### **General Warnings and Precautions**

- The information in this document should be shared with the patient.
- The patient should be informed about the importance of following the post-operative rehabilitation prescribed in order to fully understand the possible limitations in activities of daily living. The patient must be warned that failure to follow postoperative care instructions may cause the implant or treatment to fail.
- The patient must be cautioned, preferably in writing, about the use, limitations, and potential adverse effects of this device including the possibility of delayed union, non-union, device or treatment failure as a result of loose fixation and/or loosening, stress, excessive activity, or weight bearing or load bearing, and the possibility of nerve or soft tissue damage related to either surgical trauma or the presence of the device.

- Potential construct failures such as stress fractures of the bones, loosening of the construct and/or fixation, instability, delayed soft tissue healing, soft tissue irritation, delayed fusion, non-fusion, or incomplete healing may occur as a result of noncompliance to post-operative rehabilitation, excessive activities, or construct overloading.
- For safe effective use of the implant, the surgeon must be thoroughly familiar with the surgical technique for the device, implant, and associated instruments. Potential failures of the system may include delayed union, non-union, loosening of fixation, migration or failure of the device, stress fractures of the bones, or incomplete healing as a result of excessive activity, overloading or noncompliance to post-operative rehabilitation.
- The devices are not designed to withstand the stress of weight bearing, load bearing, or excessive physical activity. Device breakage may occur when the implant is subjected to excessive loading associated with delayed union, nonunion, or soft tissue healing. Improper insertion of the device during implantation may also increase the possibility of loosening, or migration.
- DO NOT reuse any of the system implantable components. Reuse may compromise the structural integrity of the construct and/or lead to failure or infection, which may result in patient injury.
- Protect the system's implantable components against scratching or nicking. Such stress concentration can lead to implant failure.
- Before using the system, inspect all implants and instruments for wear, disfiguration and physical damage. If evidence of wear, disfiguration or physical damage is found, DO NOT use and contact your local Skeletal Dynamics representative or the Skeletal Dynamics Customer Care Department.
- DO NOT permanently implant the Skeletal Dynamics K-Wires; they are only intended to be used during provisional fixation.
- Some K-Wires are double trocar. User should handle K-Wires accordingly during insertion and removal to prevent unintended K-Wire penetration or injury.
- DO NOT permanently implant the pre-loaded Drill Guides or A.I.M.ing Guides; they are intended to be removed prior to screw insertion.
- DO NOT use pin/peg/screw lengths that will excessively protrude through the far cortex as it may result in soft tissue irritation.
- DO NOT mix implant components or system specific instrumentation from different systems or manufacturers for metallurgical, biomechanical and functional reasons.
- Dispose of contaminated implants and instruments per established facility guidelines and protocols.
- Accuracy of Depth, Gap and Screw Gauges are within ± 0.25mm, 0.50mm, or 1.0mm, depending on the system.
- Caution should be taken for interference to pacemakers during electrocautery or by uncertified drills.
- Seek medical help immediately if implant malfunctions.
- To maintain traceability of the Distal Elbow Plating System implantable components, you must record each of the respective components LOT numbers into the patient records post implantation.
- The benefits from implant surgery may not meet the patient's expectations or may deteriorate over time, requiring revision surgery to replace the implant or to carry out alternative procedures.
- Care should be taken that no screws are placed in the joint.
- To maintain traceability of the system implantable components, record each of the respective components Lot numbers in the patient records post implantation.
- The system is to be used only with Skeletal Dynamics instruments, implants and accessories.

### Internal Joint Stabilizer- Elbow System Warnings and Precautions

- All screws and axis pins must be implanted and fully tightened to maintain the integrity and strength of the finished construct, and the positioning and angles established intraoperatively. If the screws or axis pins are not attached and/or fully tightened, a non-union, delayed union, soft tissue complication, or construct failure may occur.
- DO NOT violate the medial cortex of the distal humerus with the 1.5mm K-wire (Guide Wire) as it may result in nerve injury.
- The proximal end of the IJS-E System Connecting Arm must be trimmed at the level where it exits the Locking Joint if protruding. Failure to cut to the proper length may cause soft tissue irritation.
- Wear eye protection when cutting the Connecting Arm to avoid injury.
- Ensure sufficient space is available for proper application of the IJS-E System when used in conjunction with other implants to prevent interference. Interference with other prostheses may lead to failure of the IJS-E System or postoperative complications.

- The IJS-E construct is intended to be explanted when tissue healing has proved sufficient for joint stability.
- The IJS-E System has not been evaluated in patients with instability secondary to surgical release of soft tissue.
- When drilling for the IJS-E System Base Plate, be sure to avoid drilling into the articular surfaces.

#### **Distal Elbow Plating System Warnings and Precautions**

- All screws must be implanted and fully tightened to maintain the integrity and strength of the finished construct, and the positioning and angles established intraoperatively. If the screws are not attached and/or fully tightened, a non-union, delayed union, soft tissue complication, or construct failure may occur.
- When drilling for plate fixation, be sure to avoid drilling into the articular surfaces.
- Caution should be taken when contouring plates. Bending the plates may weaken or break the plates.
- The maximum angulation of the PLS should not exceed 10° from the trajectory of the respective hole.
- The PLS is not intended for placement in the proximal end of the PROTEAN Radial Head Plate as the head of the screw could sit prominent and cause soft tissue irritation.
- The Non-Locking Threaded Pegs are NOT intended to provide subchondral support. Their use should be limited to capture remote bone fragments where partially or fully threaded pegs cannot be used.

#### ALIGN Radial Head System Warnings and Precautions

- The ALIGN radial head prosthesis cannot be expected to withstand the activity levels and loads of normal healthy bone and joint tissue. Failure of the component can occur as a result of loss of fixation, strenuous activity, malalignment, trauma, non-union or excessive loads (estimated body weight equivalent of 350 lbs or greater).
- The ALIGN Head Alignment Tool must be used during the procedure to correctly align the prosthetic head and to provide the necessary counter-torque when tightening the Lock Screw.
- The T20 Drivers are single use and are to be used with the Skeletal Dynamics Torque Handle (calibrated at 60 inlbs); DO NOT reuse, reprocess or re-sterilize. Reuse may compromise the structural integrity of the construct and/or lead to failure or infection, which may result in patient injury.
- The Lock Screw packaged with the ALIGN Radial Head must be installed and fully tightened to fix the Radial Head to the Radial Stem. If the Lock Screw is not attached and/or fully secured, the Radial Head may loosen and/or disconnect from the Radial Stem, causing soft tissue irritation and/or device failure.
- The ALIGN Radial Head with Lock Screw and Radial Stems are supplied sterile using gamma radiation sterilization DO NOT use if sterile barrier is damaged or if the USE BY date has expired. Any implantable components used with an expired USE BY date will void the product warranty.

#### **Potential Adverse Events:**

The following are potential risks that have been associated with surgery: discomfort, or abnormal sensations, damage to nerves, vessels, or soft tissue, infection, edema or swelling, joint contractures, reduced or loss of ROM, bone erosion, bone fracture through bone holes, material sensitivity, intraoperative bone perforation, stiffness, nonunion, persistent pain, stiffness, disassociation, loosening or migration of the implants resulting in mal-alignment. Undesirable shortening or lengthening of limb, dislocation or subluxation due to improper positioning, implant failure, fretting and crevice corrosion may occur at interfaces between components, wear and deformation of the articular surfaces. Metal sensitivity or histological or allergic or adverse foreign body reaction resulting from implantation of a foreign material may occur.

#### **MRI Safety Information:**

The Distal Elbow Set has not been evaluated for safety and compatibility in the MR environment. It has not been tested for heating, migration, or image artifact in the MR environment. The safety of the Distal Elbow Set in the MR environment is unknown. Scanning a patient who has this device may result in patient injury.

#### Directions for Use:

The system should only be used by surgeons who have experience with this system. Each surgeon must evaluate the appropriateness for the use of the system based on their clinical experiences.

The surgeon should select the type and size implant to best meet the patient's needs. Although the surgeon is the medical intermediary between the company and the patient, this document contains important medical information that should be shared with the patient.

It is the responsibility of the surgeon to be familiar with the procedure before use of this device. Additionally, it is the responsibility of the surgeon to be familiar with relevant publications regarding the procedure prior to use. Please refer to the Surgical Technique Guide(s) to review the surgical approach as described by Jorge L. Orbay, M.D. of the *Miami Hand and Upper Extremity Institute* located in Miami, Florida.

## **Cleaning:**

The recommended manual cleaning instructions are set forth below. Other cleaning methods must be validated by the user.

#### Implant Cleaning:

The Distal Elbow Plating System implants must be cleaned thoroughly to achieve sterilization. Processing begins at the point of use. To prevent drying of soil and other contaminants, wipe blood, debris and remove gross soil from the instruments during the procedure. Implanted plates, screws, or associated components should never be re-used. Any implant that has not been used, but has become soiled, must be cleaned.

Warnings & Precautions

- Any implant contaminated with blood, tissue, and/or bodily fluids/matter should be processed according to healthcare facility protocol.
- Do not use an implant if the surface has been damaged. Damaged implants should be discarded
- Users should wear appropriate personal protective equipment (PPE).
- Users should be qualified personnel with documented evidence of training and competency. Training should be inclusive of current applicable guidelines and standards and healthcare facility policies.

#### Instrument Cleaning:

The Distal Elbow Plating System instrumentation must be cleaned thoroughly before re-use to achieve sterilization.

Warnings & Precautions

- Distal Elbow Plating System reusable instruments and accessories should be decontaminated immediately after completion of the surgical procedure. Contaminated instruments should not be allowed to dry prior to cleaning/reprocessing. Excess blood or debris should be wiped off to prevent it from drying
- Only qualified personnel with documented evidence of training and competency should clean the instruments. Training should be inclusive of current applicable guidelines and standards and healthcare facility policies.
- Avoid the use of metal brushes or scouring pads during the cleaning process.
- Instruments should be rinsed of cleaning agents to prevent residue.
- Do not use mineral oil or silicone lubricants on instruments.
- Neutral pH enzymatic and cleaning agents are recommended for cleaning instruments. It is important that alkaline cleaning agents are thoroughly neutralized and rinsed from instruments.
- Prior to sterilization, instruments should be inspected for cleanliness of surfaces, joints, and lumens, proper function, and wear and tear. If the product cannot be cleaned after repeated washing or if evidence of wear, disfiguration or physical damage is found, DO NOT use and contact your local Skeletal Dynamics representative or the Skeletal Dynamics Customer Care Department.

#### Cleaning Instructions:

Cleaning should begin at the point of use prior to processing. Keep instruments moist after use to prevent soil from drying on them. An enzymatic detergent (Enzol) was used to validate the cleaning process.

- 1. Disassemble instrumentation, if applicable.
- 2. Rinse components thoroughly under running cool tap water. While rinsing, use a soft bristle brush to loosen and remove as much visible soil as possible from components.
- 3. Soak components in a neutral enzymatic cleaner for a minimum of ten (10) minutes. Components must be fully immersed in the cleaner. Follow the cleaner manufacturer's instructions for cleaner preparation and exposure time.
- 4. Thoroughly rinse the components with cool water. While rinsing, use soft bristle brushes, pipettes or a water jet to clean out lumens, holes, and other challenging features.
- 5. Manually scrub the components thoroughly in newly made, clean, neutral pH enzymatic cleaner using soft bristle brushes or pipettes. All lumens, holes, hinged components, mating surfaces, and crevices, and

challenging components should be thoroughly scrubbed. Actuate all moveable features and expose all areas to cleaner and to the brush or pipette.

- Rinse components thoroughly with under reverse osmosis/deionized (RO/DI) water; using pipettes or a water jet to clean out lumens, holes, and other hard to reach or challenging features. Actuate all movable features to fully irrigate all areas.
- 7. Visually inspect components for soil. Repeat the cleaning procedure until no visible soil remains on the components.
- 8. Perform a final rinse on the components using running RO/DI water.
- 9. Dry the clean components using compressed air or a soft, lint free, clean cloth.

#### Sterilization:

The ALIGN Radial Head System implantable components have been sealed then sterilized by gamma radiation. The implants are provided in an undamaged package. If any of the implants or the package appears damaged, expiration date has been exceeded, or if sterility is questionable, the implant should not be used. **DO NOT re-sterilize the implantable components**. Trial components are available in the system to avoid opening the sterile package prior to prosthesis implantation. The implants should be removed from their sterile package only after the implant site has been prepared and properly sized.

The Skeletal Dynamics Distal Elbow Plating System is provided non-sterile. This system is intended for steam sterilization at the healthcare facility.

- 1. Place all components and accessories into the designated areas of the sterilization tray
- 2. Steam sterilization may be accomplished using one of the cycles shown below:

#### Cycle Times for Dynamic-Air-Removal (Vacuum) Steam Sterilization Cycles

Item	Exposure time at 132°C (270° F)	Minimum Drying Time
Wrapped Sterilization Tray	4 minutes (wrapped)	40 minutes

- Follow ANSI/AAMI ST79:2006 Comprehensive guide to steam sterilization and sterility assurance in health care facilities.
- Immediate-Use Steam Sterilization (IUSS) not recommended.
- Usage of an FDA approved sterilization container is required.
- Subsequent instrument sterilization needs to be performed in the tray system provided. For reuse and sterilization, instruments should be arranged within the tray system in the manner supplied by the company.

#### Calibration:

The Torque Handle included in the system requires calibration. DO NOT use if calibration is overdue. Contact the Skeletal Dynamics Customer Care Department to arrange for the Torque Handle to be recalibrated.

#### Handling and Storage:

When not in use, store the clean and disinfected Distal Elbow Plating System within the Sterilization Tray. Store in a cool dry place and keep away from direct sunlight. Prior to use, inspect the instrumentation for serviceability

#### Functional Checks should be performed where possible:

- 1. Mating devices should be checked for proper assembly.
- 2. Reusable devices with moving parts should be operated to check correct operation (medical grade lubricant suitable for steam sterilization can be applied as required).
- 3. Rotating instruments (e.g. drill bits, reamers) should be checked for straightness. This can be achieved by rolling the instrument on a flat surface.

**Note:** The useful life of these devices is dependent on many factors including, but not limited to the method and duration of each use and the handling of the devices between uses. Routine and careful inspection and functional testing of the device is the best method of determining the serviceable life span for the medical device.

#### **Disclaimer of Warranty and Limited Remedies:**

Skeletal Dynamics, Inc. makes no express or implied warranty, including any implied warranty of merchantability or fitness for a particular purpose, on the product(s) described in this publication. Skeletal Dynamics, Inc. shall not be liable under any circumstances for any direct, incidental or consequential damages other than as expressly provided by specific law. No person has authority to bind Skeletal Dynamics, Inc. to any representation or warranty except as specifically set forth in this publication. Descriptions or specifications provided by Skeletal Dynamics, Inc. in any

publication are only included to generally describe the product when manufactured and do not constitute any express warranties.



Customer Care Center Skeletal Dynamics, Inc. 7300 N. Kendall Dr. / Suite 800 Miami, FL 33156 1-877-753-5396



**Emergo Europe.** Westervoortsedijk 60 6827 AT Arnhem, The Netherlands







Proximal	Ulna Plates
	ates
Proximal Ulna Plate, 73mm, Right APL-PUP-3HR (01)00841506105772	Proximal Ulna Plate, 73mm, Left APL-PUP-3HL (01)00841506105789 (01) 00841506105789
Proximal Ulna Plate, 108mm, Right APL-PUP-6HR (01)00841506105802 (01) 00841506105802	Proximal Ulna Plate, 108mm, Left APL-PUP-6HL (01)00841506105819 (01)00841506105819
Proximal Ulna Plate, 151mm, Right APL-PUP-9HR (01)00841506105826 (01)00841506105826	Proximal Ulna Plate, 151mm, Left APL-PUP-9HL (01)00841506105833 (01)00841506105833
FreeFix Proximal Ulna Plate, 2 Slot, Right PUPF-2SR (01)00841506134321	FreeFix Proximal Ulna Plate, 2 Slot, Left PUPF-2SL (01)00841506134338
FreeFix Proximal Ulna Plate, 3 Slot, Right PUPF-3SR (01)00841506134345	FreeFix Proximal Ulna Plate, 3 Slot, Left PUPF-3SL (01)00841506134352
FreeFix Proximal Ulna Plate, 4 Slot, Right PUPF-4SR (01)00841506134369	FreeFix Proximal Ulna Plate, 4 Slot, Left PUPF-4SL (01)00841506134376
FreeFix Proximal Ulna Plate, 5 Slot, Right PUPF-5SR (01)00841506134383 (01)00841506134383	FreeFix Proximal Ulna Plate, 5 Slot, Left PUPF-5SL (01)00841506134390
FreeFix Proximal Ulna Plate, 5 Slot Plus, Right PUPF-5SPR (01)00841506134406 (01)00841506134406	FreeFix Proximal Ulna Plate, 5 Slot Plus, Left PUPF-5SPL (01)00841506134413
FreeFix Proximal Ulna Plate, 6 Slot, Right PUPF-6SR (01)00841506134420	FreeFix Proximal Ulna Plate, 6 Slot, Left PUPF-6SL (01)00841506134437
Proximal Ulna Plate Extension, 1 Hole PUPE-1HL (01)00841506134901	Proximal Ulna Plate Extension, 2 Hole PUPE-2HL (01)00841506134918 (01) 00841506134918
Screw, FreeFix Locking, 3.5mm	Screw, FreeFix Compression, 3.5mm
Screw, FreeFix Locking, 3.5mm x 08mm, Ti FFL-35080-TS (01)00841506129990	Screw, FreeFix Compression, 3.5mm x 08mm. Ti FFC-35080-TS (01)00841506130224 (01)00841506130224
Screw, FreeFix Locking, 3.5mm x 10mm, Ti FFL-35100-TS (01)00841506130019 (01) 00841506130019	Screw, FreeFix Compression, 3.5mm x 10mm, Ti FFC-35100-TS (01)00841506130248 (01) 00841506130248
Screw, FreeFix Locking, 3.5mm x 12mm, Ti FFL-35120-TS (01)00841506130033	Screw, FreeFix Compression, 3.5mm x 12mm, Ti FFC-35120-TS (01)00841506130262 (01)00841506130262

Screw, FreeFix Locking, 3.5mm x 14mm, Ti FFL-35140-TS	Screw, FreeFix Compression, 3.5mm x 14mm, Ti FFC-35140-TS
(01)00841506129983 (01) 00841506129983	(01)00841506129976 (01)00841506129976
Screw, FreeFix Locking, 3.5mm x 16mm, Ti FFL-35160-TS (01)00841506130064	Screw, FreeFix Compression, 3.5mm x 16mm, Ti FFC-35160-TS (01)00841506130293 (01)00841506130293
Screw, FreeFix Locking, 3.5mm x 18mm, Ti FFL-35180-TS (01)00841506130088	Screw, FreeFix Compression, 3.5mm x 18mm, Ti FFC-35180-TS (01)00841506130316 (01)00841506130316
Screw, FreeFix Locking, 3.5mm x 20mm, Ti FFL-35200-TS (01)00841506130095	Screw, FreeFix Compression, 3.5mm x 20mm. Ti FFC-35200-TS (01)00841506130323 (01)00841506130323
Screw, FreeFix Locking, 3.5mm x 22mm, Ti FFL-35220-TS (01)00841506130101	Screw, FreeFix Compression, 3.5mm x 22mm, Ti FFC-35220-TS (01)00841506130330 (01) 00841506130330
Screw, FreeFix Locking, 3.5mm x 24mm, Ti FFL-35240-TS (01)00841506130118	Screw, FreeFix Compression, 3.5mm x 24mm, Ti FFC-35240-TS (01)00841506130347
Screw, FreeFix Locking, 3.5mm x 26mm, Ti FFL-35260-TS (01)00841506130125	Screw, FreeFix Compression, 3.5mm x 26mm, Ti FFC-35260-TS (01)00841506130354 (01)00841506130354
Screw, FreeFix Locking, 3.5mm x 28mm, Ti FFL-35280-TS (01)00841506130132	Screw, FreeFix Compression, 3.5mm x 28mm, Ti FFC-35280-TS (01)00841506130361 (01)00841506130361
Screw, FreeFix Locking, 3.5mm x 30mm, Ti FFL-35300-TS (01)00841506130149	Screw, FreeFix Compression, 3.5mm x 30mm, Ti FFC-35300-TS (01)00841506130378 (01)00841506130378
Screw, FreeFix Locking, 3.5mm x 32mm, Ti FFL-35320-TS (01)00841506130156	Screw, FreeFix Compression, 3.5mm x 32mm, Ti FFC-35320-TS (01)00841506130385 (01)00841506130385
Screw, FreeFix Locking, 3.5mm x 34mm, Ti FFL-35340-TS (01)00841506130163	Screw, FreeFix Compression, 3.5mm x 34mm, Ti FFC-35340-TS (01)00841506130392 (01)00841506130392
Screw, FreeFix Locking, 3.5mm x 36mm, Ti FFL-35360-TS (01)00841506130170	Screw, FreeFix Compression, 3.5mm x 36mm, Ti FFC-35360-TS (01)00841506130408 (01)00841506130408
Screw, FreeFix Locking, 3.5mm x 38mm, Ti FFL-35380-TS (01)00841506130187	Screw, FreeFix Compression, 3.5mm x 38mm. Ti FFC-35380-TS (01)00841506130415 (01)00841506130415

Screw, FreeFix Locking, 3.5mm x 40mm, Ti	Screw, FreeFix Compression, 3.5mm x 40mm, Ti
FFL-35400-TS	FFC-35400-TS
(01)00841506130194	(01)00841506130422
(01) 00841506130194	(01)00841506130422
Screw, FreeFix Locking, 3.5mm x 42mm, Ti	Screw, FreeFix Compression, 3.5mm x 42mm, Ti
-	
FFL-35420-TS	FFC-35420-TS
(01)00841506130200	(01)00841506130439
(01)00841506130200	(01) 00841506130439
Screw, FreeFix Locking, 3.5mm x 44mm, Ti	Screw, FreeFix Compression, 3.5mm x 44mm, Ti
FFL-35440-TS	FFC-35440-TS
(01)00841506130217	(01)00841506130446
(01)00841506130217	(01) 00841506130446
Courses Multi Thusad Lasting 2 From	Concern Multi Thread Companying 2 From
Screw, Multi-Thread Locking, 3.5mm	Screw, Multi-Thread Compression, 3.5mm
Screw, Multi-Thread Locking, 3.5mm x 8mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 8mm, Ti
MTLS-35080-TS	MTNL-35080-TS
(01)00841506106557	(01)00841506106564
(01)00841506106557	(01)00841506106564
Screw, Multi-Thread Locking, 3.5mm x 10mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 10mm, Ti
MTLS-35100-TS	MTNL-35100-TS
E7272	L'ANR
(01)00841506106670	(01)00841506106885
(01)00841506106670	
Screw, Multi-Thread Locking, 3.5mm x 12mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 12mm, Ti
MTLS-35120-TS	MTNL-35120-TS
(01)00841506106687	(01)00841506106892
(01)00841506106687	(01) 00841506106892
Screw, Multi-Thread Locking, 3.5mm x 14mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 14mm, Ti
MTLS-35140-TS	MTNL-35140-TS
(01)00841506106694	(01)00841506106908
(01) 00841506106694	
Screw, Multi-Thread Locking, 3.5mm x 16mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 16mm, Ti
MTLS-35160-TS	MTNL-35160-TS
(01)00841506106700	(01)00841506106915
(01)00841506106700	(01)00841506106915
Screw, Multi-Thread Locking, 3.5mm x 18mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 18mm, Ti
MTLS-35180-TS	MTNL-35180-TS
(01)00841506106717	
(01)00041500100717 (01)00841506106717	
Screw, Multi-Thread Locking, 3.5mm x 20mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 20mm, Ti
MTLS-35200-TS	MTNL-35200-TS
(01)00841506106724	(01)00841506106939
(01)00841506106724	(01)00841506106939
Screw, Multi-Thread Locking, 3.5mm x 22mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 22mm, Ti
MTLS-35220-TS	MTNL-35220-TS
(01)00841506106731	(01)00841506106946
(01)00841500100751 (01)00841506106731	(01)00841506106946
Screw, Multi-Thread Locking, 3.5mm x 24mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 24mm, Ti
MTLS-35240-TS	MTNL-35240-TS
(01)00841506106748	(01)00841506106953
(01)00841506106748	(01)00841506106953
Screw, Multi-Thread Locking, 3.5mm x 26mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 26mm, Ti
MTLS-35260-TS	MTNL-35260-TS
(01)00841506106755	(01)00841506106960
(01)00841506106755 (01)00841506106755	
(01)00841506106755	(01)00841506106960

Screw, Multi-Thread Locking, 3.5mm x 28mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 28mm, Ti
MTLS-35280-TS	MTNL-35280-TS
(01)00841506106762	(01)00841506106977
(01)00841506106762	(01)00841506106977
Screw, Multi-Thread Locking, 3.5mm x 30mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 30mm, Ti
MTLS-35300-TS	MTNL-35300-TS
(01)00841506106779	(01)00841506106984
(01)00841506106779	(01)00841506106984
Screw, Multi-Thread Locking, 3.5mm x 32mm, Ti MTLS-35320-TS (01)00841506106786 (01)00841506106786	Screw, Multi-Thread Compression, 3.5mm x 32mm, Ti MTNL-35320-TS (01)00841506106991
Screw, Multi-Thread Locking, 3.5mm x 34mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 34mm, Ti
MTLS-35340-TS	MTNL-35340-TS
(01)00841506106793	(01)00841506107004
(01)00841506106793	(01)00841506107004
Screw, Multi-Thread Locking, 3.5mm x 36mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 36mm, Ti
MTLS-35360-TS	MTNL-35360-TS
(01)00841506106809	(01)00841506107011
(01)00841506106809	(01)00841506107011
Screw, Multi-Thread Locking, 3.5mm x 38mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 38mm, Ti
MTLS-35380-TS	MTNL-35380-TS
(01)00841506106816	(01)00841506107028
(01)00841506106816	(01) 00841506107028
Screw, Multi-Thread Locking, 3.5mm x 40mm, Ti MTLS-35400-TS (01)00841506106823 (01)00841506106823	Screw, Multi-Thread Compression, 3.5mm x 40mm, Ti MTNL-35400-TS (01)00841506107035
Screw, Multi-Thread Locking, 3.5mm x 42mm. Ti MTLS-35420-TS (01)00841506117942 (01) 00841506117942	Screw, Multi-Thread Compression, 3.5mm x 42mm. Ti MTNL-35420-TS (01)00841506117980
Screw, Multi-Thread Locking, 3.5mm x 44mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 44mm, Ti
MTLS-35440-TS	MTNL-35440-TS
(01)00841506117959	(01)00841506117997
Screw, Multi-Thread Locking, 3.5mm x 45mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 45mm, Ti
MTLS-35450-TS	MTNL-35450-TS
(01)00841506106830	(01)00841506107042
(01) 00841506106830	(01) 00841506107042
Screw, Multi-Thread Locking, 3.5mm x 46mm, Ti MTLS-35460-TS (01)00841506117966 (01)00841506117966	Screw, Multi-Thread Compression, 3.5mm x 46mm, Ti MTNL-35460-TS (01)00841506118000
Screw, Multi-Thread Locking, 3.5mm x 48mm, Ti MTLS-35480-TS (01)00841506117973 (01)00841506117973	Screw, Multi-Thread Compression, 3.5mm x 48mm, Ti MTNL-35480-TS (01)00841506118017
Screw, Multi-Thread Locking, 3.5mm x 50mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 50mm, Ti
MTLS-35500-TS	MTNL-35500-TS
(01)00841506106847	(01)00841506107059
(01)00841506106847	(01) 00841506107059

Screw, Multi-Thread Locking, 3.5mm x 55mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 55mm, Ti
MTLS-35550-TS	MTNL-35550-TS
(01)00841506106854	(01)00841506107066
(01)0084150610685	. ,
Screw, Multi-Thread Locking, 3.5mm x 60mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 60mm, Ti
MTLS-35600-TS	MTNL-35600-TS
(01)00841506106861	(01)00841506107073
(01)0084150610686	. ,
Screw, Multi-Thread Locking, 3.5mm x 65mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 65mm, Ti
	DIMOIL
MTLS-35650-TS	MTNL-35650-TS
(01)00841506107196	(01)00841506107202
(01)0084150610719	(01)00841506107202
Screw, Multi-Thread Locking, 3.5mm x 70mm, Ti	Screw, Multi-Thread Compression, 3.5mm x 70mm, Ti
MTLS-35700-TS	MTNL-35700-TS
LT 3768	- <b></b>
(01)00841506106878 (01) 00841506106878	(01)00841506107080
(01)0084150610687	(01)00841506107080
Instru	mentation
AlMing Guides, 2.0mm	K-Wire, Standard Tip, 2.0 mm x 152 mm
PDG-AIM-020	KWIR-STD-20152
(01)00841506106571	(01)00841506106588
(01)00041500100571 (01)0084150610657	
	(01)0004150510550
AIMing Guides, 2.0mm Snap Fit	
PDG-AIM-20SF	
(01)00841506117843	
(01)0084150611784	3
	-Elbow
	Plate
IJS-E Base Plate Assembly	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate
	Plate
IJS-E Base Plate Assembly	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate
IJS-E Base Plate Assembly IJS-ELB-BPA	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107
IJS-E Base Plate Assembly IJS-ELB-BPA (01)00841506104904	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107 (01)00841506109107
IJS-E Base Plate Assembly IJS-ELB-BPA (01)00841506104904 Double IJS-E, Assembly	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107 (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate
IJS-E Base Plate Assembly IJS-ELB-BPA (01)00841506104904 Double IJS-E, Assembly IJS-DBL-BPA	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107 (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate IJS-DBL-PUP
IJS-E Base Plate Assembly IJS-ELB-BPA (01)00841506104904 Double IJS-E, Assembly	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107 (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate
IJS-E Base Plate Assembly IJS-ELB-BPA (01)00841506104904 Double IJS-E, Assembly IJS-DBL-BPA	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate IJS-DBL-PUP (01)00841506131559
IJS-E Base Plate Assembly IJS-ELB-BPA (01)00841506104904 Double IJS-E, Assembly IJS-DBL-BPA (01)00841506109138	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate IJS-DBL-PUP (01)00841506131559
IJS-E Base Plate Assembly         IJS-ELB-BPA         (01)00841506104904         Double IJS-E, Assembly         IJS-DBL-BPA         (01)00841506109138         #4-40 Screws	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate IJS-DBL-PUP (01)00841506131559
IJS-E Base Plate Assembly IJS-ELB-BPA (01)00841506104904 Double IJS-E, Assembly IJS-DBL-BPA (01)00841506109138 (01)00841506109138 #4-40 Screws IJS-PUP-SCRW	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate IJS-DBL-PUP (01)00841506131559
IJS-E Base Plate Assembly         IJS-ELB-BPA         (01)00841506104904         Double IJS-E, Assembly         IJS-DBL-BPA         (01)00841506109138         #4-40 Screws         IJS-PUP-SCRW         (01)00841506107226	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate IJS-DBL-PUP (01)00841506131559 (01)00841506131559
IJS-E Base Plate Assembly         IJS-ELB-BPA         (01)00841506104904         Double IJS-E, Assembly         IJS-DBL-BPA         (01)00841506109138         #4-40 Screws         IJS-PUP-SCRW         (01)00841506107226	Plate         IJS-E Base Plate Assembly, Proximal Ulna Plate         IJS-PUP-BPA         (01)00841506109107         (01)00841506109107         Double IJS-E, Assembly, Proximal Ulna Plate         IJS-DBL-PUP         (01)00841506131559         (01)00841506131559
IJS-E Base Plate Assembly         IJS-ELB-BPA         (01)00841506104904         Double IJS-E, Assembly         IJS-DBL-BPA         (01)00841506109138         #4-40 Screws         IJS-PUP-SCRW         (01)00841506107226         Screw, Cortical	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate IJS-DBL-PUP (01)00841506131559 (01)00841506131559
IJS-E Base Plate Assembly         IJS-ELB-BPA         (01)00841506104904         Double IJS-E, Assembly         IJS-DBL-BPA         (01)00841506109138         #4-40 Screws         IJS-PUP-SCRW         (01)00841506107226	Plate         IJS-E Base Plate Assembly, Proximal Ulna Plate         IJS-PUP-BPA         (01)00841506109107         (01)00841506109107         Double IJS-E, Assembly, Proximal Ulna Plate         IJS-DBL-PUP         (01)00841506131559         (01)00841506131559
IJS-E Base Plate Assembly         IJS-ELB-BPA         (01)00841506104904         Double IJS-E, Assembly         IJS-DBL-BPA         (01)00841506109138         #4-40 Screws         IJS-PUP-SCRW         (01)00841506107226         Screw, Cortical         Screw, Cortical Non-Locking, 3.5mm x 08mm, Tite	Plate         IJS-E Base Plate Assembly, Proximal Ulna Plate         IJS-PUP-BPA         (01)00841506109107         (01)00841506109107         Double IJS-E, Assembly, Proximal Ulna Plate         IJS-DBL-PUP         (01)00841506131559         (01)00841506131559         (01)00841506131559         Screw, Cortical Non-Locking, 3.5mm x 28mm, Ti
IJS-E Base Plate Assembly         IJS-ELB-BPA         (01)00841506104904         Double IJS-E, Assembly         IJS-DBL-BPA         (01)00841506109138         #4-40 Screws         IJS-PUP-SCRW         (01)00841506107226         Screw, Cortical Non-Locking, 3.5mm x 08mm, Ti         PANL-35080-TS	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate IJS-DBL-PUP (01)00841506131559 (01)00841506131559 (01)00841506131559 (01)00841506131559 (01)00841506131559 (01)00841506131559
IJS-E Base Plate Assembly         IJS-ELB-BPA         (01)00841506104904         Double IJS-E, Assembly         IJS-DBL-BPA         (01)00841506109138         #4-40 Screws         IJS-PUP-SCRW         (01)00841506107226         Screw, Cortical Non-Locking, 3.5mm x 08mm, Ti         PANL-35080-TS         (01)00841506102771	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate IJS-DBL-PUP (01)00841506131559 (01)00841506131559 (01)00841506131559 Screw, Cortical Non-Locking, 3.5mm x 28mm, Ti PANL-35280-TS (01)00841506104218
IJS-E Base Plate Assembly         IJS-ELB-BPA         (01)00841506104904         Double IJS-E, Assembly         IJS-DBL-BPA         (01)00841506109138         #4-40 Screws         IJS-PUP-SCRW         (01)00841506107226         Screw, Cortical         Screw, Cortical Non-Locking, 3.5mm x 08mm, Ti         PANL-35080-TS         (01)00841506102771	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate IJS-DBL-PUP (01)00841506131559 (01)00841506131559 (01)00841506131559 (01)00841506104218 (01)00841506104218 (01)00841506104218
IJS-E Base Plate Assembly         IJS-ELB-BPA         (01)00841506104904         Double IJS-E, Assembly         IJS-DBL-BPA         (01)00841506109138         #4-40 Screws         IJS-PUP-SCRW         (01)00841506107226         Screw, Cortical         Screw, Cortical Non-Locking, 3.5mm x 08mm, Ti         PANL-35080-TS         (01)00841506102771         Screw, Cortical Non-Locking, 3.5mm x 10mm. Ti	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate IJS-DBL-PUP (01)00841506131559 (01)00841506131559 (01)00841506131559 Screw, Cortical Non-Locking, 3.5mm x 28mm, Ti PANL-35280-TS (01)00841506104218 (01)00841506104218 (01)00841506104218
IJS-E Base Plate Assembly         IJS-ELB-BPA         (01)00841506104904         Double IJS-E, Assembly         IJS-DBL-BPA         (01)00841506109138         #4-40 Screws         IJS-PUP-SCRW         (01)00841506107226         Screw, Cortical         Screw, Cortical Non-Locking, 3.5mm x 08mm, Ti         PANL-35080-TS         (01)00841506102771	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate IJS-DBL-PUP (01)00841506131559 (01)00841506131559 (01)00841506131559 (01)00841506104218 (01)00841506104218 (01)00841506104218
IJS-E Base Plate Assembly         IJS-ELB-BPA         (01)00841506104904         Double IJS-E, Assembly         IJS-DBL-BPA         (01)00841506109138         #4-40 Screws         IJS-PUP-SCRW         (01)00841506107226         Screw, Cortical Non-Locking, 3.5mm x 08mm, Ti         PANL-35080-TS         (01)00841506102771         Screw, Cortical Non-Locking, 3.5mm x 10mm, Ti         PANL-35100-TS	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate IJS-DBL-PUP (01)00841506131559 (01)00841506131559 (01)00841506131559 Screw, Cortical Non-Locking, 3.5mm x 28mm, Ti PANL-35280-TS (01)00841506104218 Screw, Cortical Non-Locking, 3.5mm x 30mm, Ti PANL-35300-TS
IJS-E Base Plate Assembly         IJS-ELB-BPA         (01)00841506104904         Double IJS-E, Assembly         IJS-DBL-BPA         (01)00841506109138         #4-40 Screws         IJS-PUP-SCRW         (01)00841506107226         Screw, Cortical         Screw, Cortical Non-Locking, 3.5mm x 08mm, Ti         PANL-35080-TS         (01)00841506102771         Screw, Cortical Non-Locking, 3.5mm x 10mm. Ti	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate IJS-DBL-PUP (01)00841506131559 (01)00841506131559 (01)00841506131559 (01)00841506104218 Screw, Cortical Non-Locking, 3.5mm x 28mm, Ti PANL-35280-TS (01)00841506104218 Screw, Cortical Non-Locking, 3.5mm x 30mm, Ti PANL-35300-TS (01)00841506104225
IJS-E Base Plate Assembly         IJS-ELB-BPA         (01)00841506104904         Double IJS-E, Assembly         IJS-DBL-BPA         (01)00841506109138         (01)00841506109138         #4-40 Screws         IJS-PUP-SCRW         (01)00841506107226         Screw, Cortical Non-Locking, 3.5mm x 08mm, Ti         PANL-35080-TS         (01)00841506102771         Screw, Cortical Non-Locking, 3.5mm x 10mm. Ti         PANL-35100-TS         (01)00841506102795         (01)00841506102795	Plate         IJS-E Base Plate Assembly, Proximal Ulna Plate         IJS-PUP-BPA       (01)00841506109107         (01)00841506109107       (01)00841506109107         Double IJS-E, Assembly, Proximal Ulna Plate       IJS-DBL-PUP         (01)00841506131559       (01)00841506131559         (01)00841506131559       (01)00841506131559         Screw, Cortical Non-Locking, 3.5mm x 28mm, Ti         PANL-35280-TS       (01)00841506104218         Screw, Cortical Non-Locking, 3.5mm x 30mm, Ti         PANL-35300-TS       (01)00841506104225         (01)00841506104225       (01)00841506104225
IJS-E Base Plate Assembly         IJS-ELB-BPA         (01)00841506104904         Double IJS-E, Assembly         IJS-DBL-BPA         (01)00841506109138         #4-40 Screws         IJS-PUP-SCRW         (01)00841506107226         Screw, Cortical Non-Locking, 3.5mm x 08mm, Ti         PANL-35080-TS         (01)00841506102771         Screw, Cortical Non-Locking, 3.5mm x 10mm. Ti         PANL-35100-TS         (01)00841506102795         (01)00841506102795         (01)00841506102795	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate IJS-DBL-PUP (01)00841506131559 (01)00841506131559 (01)00841506131559 (01)00841506104218 (01)00841506104218 (01)00841506104218 Screw, Cortical Non-Locking, 3.5mm x 30mm, Ti PANL-35300-TS (01)00841506104225 (01)00841506104225 Screw, Cortical Non-Locking, 3.5mm x 32mm, Ti PANL-35300-TS (01)00841506104225 Screw, Cortical Non-Locking, 3.5mm x 32mm, Ti PANL-35300-TS (01)00841506104225
IJS-E Base Plate Assembly         IJS-ELB-BPA         (01)00841506104904         Double IJS-E, Assembly         IJS-DBL-BPA         (01)00841506109138         #4-40 Screws         IJS-PUP-SCRW         (01)00841506107226         Screw, Cortical Non-Locking, 3.5mm x 08mm, Ti         PANL-35080-TS         (01)00841506102771         Screw, Cortical Non-Locking, 3.5mm x 10mm. Ti         PANL-35100-TS         (01)00841506102795         (01)00841506102795	Plate US-E Base Plate Assembly, Proximal Ulna Plate US-PUP-BPA (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate US-DBL-PUP (01)00841506131559 (01)00841506131559 (01)00841506131559 (01)00841506131559 (01)00841506104218 (01)00841506104218 Screw, Cortical Non-Locking, 3.5mm x 28mm, Ti PANL-35280-TS (01)00841506104218 Screw, Cortical Non-Locking, 3.5mm x 30mm, Ti PANL-35300-TS (01)00841506104225 Screw, Cortical Non-Locking, 3.5mm x 32mm, Ti PANL-35320-TS (01)00841506104225 Screw, Cortical Non-Locking, 3.5mm x 32mm, Ti PANL-35320-TS
IJS-E Base Plate Assembly         IJS-ELB-BPA         (01)00841506104904         Double IJS-E, Assembly         IJS-DBL-BPA         (01)00841506109138         #4-40 Screws         IJS-PUP-SCRW         (01)00841506107226         Screw, Cortical Non-Locking, 3.5mm x 08mm, Ti         PANL-35080-TS         (01)00841506102771         Screw, Cortical Non-Locking, 3.5mm x 10mm. Ti         PANL-35100-TS         (01)00841506102795         (01)00841506102795         (01)00841506102795	Plate IJS-E Base Plate Assembly, Proximal Ulna Plate IJS-PUP-BPA (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate IJS-DBL-PUP (01)00841506131559 (01)00841506131559 (01)00841506131559 (01)00841506104218 (01)00841506104218 (01)00841506104218 Screw, Cortical Non-Locking, 3.5mm x 30mm, Ti PANL-35300-TS (01)00841506104225 (01)00841506104225 Screw, Cortical Non-Locking, 3.5mm x 32mm, Ti PANL-35300-TS (01)00841506104225 Screw, Cortical Non-Locking, 3.5mm x 32mm, Ti PANL-35300-TS (01)00841506104225
IJS-E Base Plate Assembly         IJS-ELB-BPA         (01)00841506104904         Double IJS-E, Assembly         IJS-DBL-BPA         (01)00841506109138         #4-40 Screws         IJS-PUP-SCRW         (01)00841506107226         Screw, Cortical Non-Locking, 3.5mm x 08mm, Ti         PANL-35080-TS         (01)00841506102771         Screw, Cortical Non-Locking, 3.5mm x 10mm. Ti         PANL-35100-TS         (01)00841506102795         (01)00841506102795	Plate US-E Base Plate Assembly, Proximal Ulna Plate US-PUP-BPA (01)00841506109107 Double IJS-E, Assembly, Proximal Ulna Plate US-DBL-PUP (01)00841506131559 (01)00841506131559 (01)00841506131559 (01)00841506104218 (01)00841506104218 (01)00841506104218 Screw, Cortical Non-Locking, 3.5mm x 30mm, Ti PANL-35300-TS (01)00841506104225 Screw, Cortical Non-Locking, 3.5mm x 32mm, Ti PANL-35300-TS (01)00841506104225 Screw, Cortical Non-Locking, 3.5mm x 32mm, Ti PANL-35320-TS (01)00841506104225 Screw, Cortical Non-Locking, 3.5mm x 32mm, Ti PANL-35320-TS (01)00841506104225

Screw, Cortical Non-Locking, 3.5mm x PANL-35140-TS (01)00841506102832 Screw, Cortical Non-Locking, 3.5mm x PANL-35160-TS (01)00841506102856 Screw, Cortical Non-Locking, 3.5mm x PANL-35180-TS	(01) 00841506102832 16mm, Ti (01) 00841506102856	Screw, Cortical Non-Locking, 3.5mm x 3 PANL-35340-TS (01)00841506104249 Screw, Cortical Non-Locking, 3.5mm x 3 PANL-35360-TS (01)00841506104256 Screw, Cortical Non-Locking, 3.5mm x 3 PANL-35380-TS	(01) 00841506104249 6mm. Ti (01) 00841506104256
(01)00841506102863 Screw, Cortical Non-Locking, 3.5mm x PANL-35200-TS	(01) 00841506102863 20mm, Ti	(01)00841506104263 Screw, Cortical Non-Locking, 3.5mm x 4 PANL-35400-TS	(01) 00841506104263 Omm, Ti
(01)00841506104171 Screw, Cortical Non-Locking, 3.5mm x PANL-35220-TS	(01) 00841506104171 22mm, Ti	(01)00841506104270 Screw, Cortical Non-Locking, 3.5mm x 4 PANL-35420-TS	(01) 00841506104270 2mm, Ti
(01)00841506104188 Screw, Cortical Non-Locking, 3.5mm x PANL-35240-TS (01)00841506104195	(01) 00841506104188 24mm, Ti	(01)00841506104287 Screw, Cortical Non-Locking, 3.5mm x 4 PANL-35440-TS (01)00841506104294	(01) 00841506104287 4mm, Ti
Screw, Cortical Non-Locking, 3.5mm x PANL-35260-TS (01)00841506104201	(01) 00841506104201		(01) 00841506104294
	Axis	s Pins	
IJS-E Axis Pin 2.5mm x 30mm IJS-EAP-25300 (01)00841506105062	(01) 00841506105062	IJS-E Axis Pin 2.5mm x 55mm IJS-EAP-25550 (01)00841506105116	(01) 00841506105116
IJS-E Axis Pin 2.5mm x 35mm IJS-EAP-25350 (01)00841506105079	(01) 00841506105079	IJS-E Axis Pin 2.5mm x 60mm IJS-EAP-25600 (01)00841506105123	(01) 00841506105123
IJS-E Axis Pin 2.5mm x 40mm IJS-EAP-25400 (01)00841506105086	(01) 00841506105086	IJS-E Axis Pin 2.5mm x 65mm IJS-EAP-25650 (01)00841506105130	(01) 00841506105130
IJS-E Axis Pin 2.5mm x 45mm IJS-EAP-25450 (01)00841506105093	(01) 00841506105093	IJS-E Axis Pin 2.5mm x 70mm IJS-EAP-25700 (01)00841506105147	(01) 00841506105147
IJS-E Axis Pin 2.5mm x 50mm IJS-EAP-25500 (01)00841506105109	(01) 00841506105109	IJS-E Axis Pin Female, 30mm IJS-EAP-F30 (01)00841506114019	(01) 00841506114019
		entation	
K-Wire Standard Tip, 1.5mm x 127mm KWIR-DES-15127 (01)00841506107318	(01) 00841506107318		

	ory Control Sheet
	Compression Screws
	& Instrumentation
Screw, Headless Compression, 3.5mm x 10mm, Ti HCS-35010 (01)00841506101941	Screw, Headless Compression, 3.5mm x 26mm, Ti HCS-35026 (01)00841506102023
Screw, Headless Compression, 3.5mm x 12mm, Ti HCS-35012 (01)00841506101958	Screw, Headless Compression, 3.5mm x 28mm, Ti HCS-35028 (01)00841506102030
Screw, Headless Compression, 3.5mm x 14mm, Ti HCS-35014 (01)00841506101965	Screw, Headless Compression, 3.5mm x 30mm, Ti HCS-35030 (01)00841506102047
Screw, Headless Compression, 3.5mm x 16mm, Ti HCS-35016 (01)00841506101972	Screw, Headless Compression, 3.5mm x 35mm, Ti HCS-35035 (01)00841506105840
Screw, Headless Compression, 3.5mm x 18mm, Ti HCS-35018 (01)00841506101989	Screw, Headless Compression, 3.5mm x 40mm, Ti HCS-35040 (01)00841506105857
Screw, Headless Compression, 3.5mm x 20mm, Ti HCS-35020 (01)00841506101996	Screw, Headless Compression, 3.5mm x 45mm, Ti HCS-35045 (01)00841506105864 (01)00841506105864
Screw, Headless Compression, 3.5mm x 22mm, Ti HCS-35022 (01)00841506102009	K-Wire, 1.4mm x 165mm, Double Trocar KWIR-HCS-14165 (01)00841506102481
Screw, Headless Compression, 3.5mm x 24mm, Ti HCS-35024 (01)00841506102016	
2.5mm Screws 8	& Instrumentation
Screw, Headless Compression, 2.5mm x 10mm, Ti HCS-25010 (01)00841506101835	Screw, Headless Compression, 2.5mm x 22mm, Ti HCS-25022 (01)00841506101897
Screw, Headless Compression, 2.5mm x 12mm, Ti HCS-25012 (01)00841506101842	Screw, Headless Compression, 2.5mm x 24mm, Ti HCS-25024 (01)00841506101903 (01)00841506101903
Screw, Headless Compression, 2.5mm x 14mm, Ti HCS-25014 (01)00841506101859	Screw, Headless Compression, 2.5mm x 26mm, Ti HCS-25026 (01)00841506101910
Screw, Headless Compression, 2.5mm x 16mm, Ti HCS-25016 (01)00841506101866 (01) 00841506101866	Screw, Headless Compression, 2.5mm x 28mm, Ti HCS-25028 (01)00841506101927
Screw, Headless Compression, 2.5mm x 18mm, Ti HCS-25018 (01)00841506101873 (01) 00841506101873	Screw, Headless Compression, 2.5mm x 30mm, Ti HCS-25030 (01)00841506101934

Inventory Control Sheet

Screw, Headless Compression, 2.5mm x 20mm,	
HCS-25020	à
(01)00841506101880	ļ



K-Wire, 0.9mm x 152mm, Double Trocar KWIR-HCS-09152 (01)00841506109145



(01)00841506109145

Fragmen	t Fixation
	N Plates
Assembled, PROTEAN Radial Head Plate, Right	Assembled, PROTEAN Fragment Plate, Y
PRT-RHP-RT	PRT-FSP-YS
(01)00841506104669	(01)00841506102931
Assembled, PROTEAN Radial Head Plate, Left	Assembled, PROTEAN Coronoid Plate, Right
PRT-RHP-LT	PRT-CRD-RT
(01)00841506104652	(01)00841506108872
Assembled, PROTEAN Fragment Plate, Double Hockey Stick PRT-FSP-LR (01)00841506102917 (01)00841506102917	Assembled, PROTEAN Coronoid Plate, Left PRT-CRD-LT (01)00841506108889 (01)00841506108889
Assembled, Extended PROTEAN Radial Head Plate, Right	Assembled, Extended PROTEAN Radial Head Plate, Left
PRT-RHP-ERT	PRT-RHP-ELT
(01)00841506117102	(01)00841506117119
Threaded Peg, Cortical Non-Locking, 2.7mm	Threaded Peg, Fluted, Locking, 2.3mm
Threaded Peg, Cortical Non-Locking, 2.7mm x 10mm, Ti	Threaded Peg, Fluted, Locking, 2.3mm x 10mm, Ti
PANL-27100-TS	TPFL-23100-TS
(01)00841506105970	(01)00841506104713
(01)00841506105970	(01) 00841506104713
Threaded Peg, Cortical Non-Locking, 2.7mm x 12mm, Ti	Threaded Peg, Fluted, Locking, 2.3mm x 12mm, Ti
PANL-27120-TS	TPFL-23120-TS
(01)00841506105987	(01)00841506104720
Threaded Peg, Cortical Non-Locking, 2.7mm x 14mm, Ti PANL-27140-TS (01)00841506105994 (01)00841506105994	Threaded Peg, Fluted, Locking, 2.3mm x 14mm, Ti TPFL-23140-TS (01)00841506104737
Threaded Peg, Cortical Non-Locking, 2.7mm x 16mm, Ti	Threaded Peg, Fluted, Locking, 2.3mm x 16mm, Ti
PANL-27160-TS	TPFL-23160-TS
(01)00841506106007	(01)00841506104744
Threaded Peg, Cortical Non-Locking, 2.7mm x 18mm, Ti PANL-27180-TS (01)00841506106014 (01)00841506106014	Threaded Peg, Fluted, Locking, 2.3mm x 18mm, Ti TPFL-23180-TS (01)00841506104751
Threaded Peg, Cortical Non-Locking, 2.7mm x 20mm, Ti	Threaded Peg, Fluted, Locking, 2.3mm x 20mm, Ti
PANL-27200-TS	TPFL-23200-TS
(01)00841506106021	(01)00841506104775
Threaded Peg, Cortical Non-Locking, 2.7mm x 22mm. Ti	Threaded Peg, Fluted, Locking, 2.3mm x 22mm. Ti
PANL-27220-TS	TPFL-23220-TS
(01)00841506106038	(01)00841506104799
(01)00841506106038	(01) 00841506104799
Threaded Peg, Cortical Non-Locking, 2.7mm x 24mm, Ti	Threaded Peg, Fluted, Locking, 2.3mm x 24mm. Ti
PANL-27240-TS	TPFL-23240-TS
(01)00841506106045	(01)00841506104812
(01)00841506106045	(01)00841506104812

Invento	ory Control Sheet
Threaded Peg, Cortical Non-Locking, 2.7mm x 26mm, Ti PANL-27260-TS (01)00841506106052	Threaded Peg, Fluted, Locking, 2.3mm x 26mm, Ti TPFL-23260-TS (01)00841506104829 (01)00841506104829
Threaded Peg, Cortical Non-Locking, 2.7mm x 28mm, Ti PANL-27280-TS (01)00841506106069 (01)00841506106069	Threaded Peg, Fluted, Locking, 2.3mm x 28mm, Ti TPFL-23280-TS (01)00841506104836 (01) 00841506104836
Threaded Peg, Cortical Non-Locking, 2.7mm x 30mm, Ti PANL-27300-TS (01)00841506106076	Threaded Peg, Fluted, Locking, 2.3mm x 30mm, Ti TPFL-23300-TS (01)00841506104843
Threaded Peg, Cortical Non-Locking, 2.7mm x 32mm, Ti PANL-27320-TS (01)00841506106083	Threaded Peg, Fluted, Locking, 2.3mm x 32mm, Ti TPFL-23320-TS (01)00841506104850 (01)00841506104850
Threaded Peg, Cortical Non-Locking, 2.7mm x 36mm, Ti PANL-27360-TS (01)00841506106106 (01)00841506106106	Threaded Peg, Fluted, Locking, 2.3mm x 36mm, Ti TPFL-23360-TS (01)00841506104874
Threaded Peg, Cortical Non-Locking, 2.7mm x 40mm, Ti         PANL-27400-TS         (01)00841506106120         (01)00841506106120	Threaded Peg, Fluted, Locking, 2.3mm x 40mm, Ti TPFL-23400-TS (01)00841506107325
High Compression	Locking Peg, 2.7mm
High Compression Locking Peg, 2.7mm x 10mm, Ti HCLP-27100-TS (01)00841506101682	High Compression Locking Peg, 2.7mm x 24mm, Ti HCLP-27240-TS (01)00841506101781
High Compression Locking Peg, 2.7mm x 12mm, Ti HCLP-27120-TS (01)00841506101699	High Compression Locking Peg, 2.7mm x 26mm, Ti HCLP-27260-TS (01)00841506101798
High Compression Locking Peg, 2.7mm x 14mm, Ti HCLP-27140-TS (01)00841506101705	High Compression Locking Peg, 2.7mm x 28mm, Ti HCLP-27280-TS (01)00841506101804
High Compression Locking Peg, 2.7mm x 16mm, Ti HCLP-27160-TS (01)00841506101712	High Compression Locking Peg, 2.7mm x 30mm, Ti HCLP-27300-TS (01)00841506101811
High Compression Locking Peg, 2.7mm x 18mm, Ti HCLP-27180-TS (01)00841506101729	High Compression Locking Peg, 2.7mm x 32mm, Ti HCLP-27320-TS (01)00841506101828 (01)00841506101828
High Compression Locking Peg, 2.7mm x 20mm. Ti HCLP-27200-TS (01)00841506101743	Washer, Button (Bronze) WBTN-HCLP (01)00841506105963
High Compression Locking Peg, 2.7mm x 22mm, Ti	

	Invento	ory Control Sheet	
	Instrum	entation	
K-Wire, 1.5mm x 127mm		AIMing Guides, 1.5mm	
KWIR-DES-15127	2332	PDG-AIM-015	1240年
(01)00841506107318	100 C	(01)00841506102870	228 - C
	(01)00841506105956		(01)00841506102870
	Polyaxial Lo	cking Screws	
		I Locking Screws	
Screw, Polyaxial Locking, 3.0mm x 20mm		Screw, Polyaxial Locking, 3.0mm x 32mm	Cannulated,
CoCr	1997	CoCr	E SARE
PALS-30200-CC		PALS-30320-CC	1 B
(01)00841506106595	(01)00841506106595	(01)00841506107141	(01)00841506107141
Screw, Polyaxial Locking, 3.0mm x 22mm	n Cannulated,	Screw, Polyaxial Locking, 3.0mm x 34mm	Cannulated,
CoCr		CoCr	1000 V2
PALS-30220-CC	24242	PALS-30340-CC	1000 C
(01)00841506107097	(01)00841506107097	(01)00841506107158	(01)00841506107158
Screw, Polyaxial Locking, 3.0mm x 24mm	n Cannulated,	Screw, Polyaxial Locking, 3.0mm x 36mm	Cannulated,
CoCr		CoCr	10000
PALS-30240-CC	1 <u>128</u>	PALS-30360-CC	
(01)00841506107103	(01)00841506107103	(01)00841506107165	(01)00841506107165
Screw, Polyaxial Locking, 3.0mm x 26mm	n Cannulated,	Screw, Polyaxial Locking, 3.0mm x 38mm	Cannulated,
CoCr		CoCr	
PALS-30260-CC		PALS-30380-CC	836
(01)00841506107110	(01)00841506107110	(01)00841506107172	(01)00841506107172
Screw, Polyaxial Locking, 3.0mm x 28mm	n Cannulated.	Screw, Polyaxial Locking, 3.0mm x 40mm	Cannulated,
CoCr		CoCr	
PALS-30280-CC	112345	PALS-30400-CC	522
(01)00841506107127	(01)00841506107127	(01)00841506107189	(01)00841506107189
Screw, Polyaxial Locking, 3.0mm x 30mm	n Cannulated.		
	PERSONAL S		
CoCr	138		
CoCr PALS-30300-CC			
CoCr PALS-30300-CC (01)00841506107134	(01) 00841506107134		
CoCr PALS-30300-CC (01)00841506107134 <b>3.0mm</b>	(01) 00841506107134	g Screw Instrumentation	
CoCr PALS-30300-CC (01)00841506107134 <b>3.0mm</b> K-Wire, Standard Tip, 1.1 mm x 152 mm	(01) 00841506107134	PLS AIMing Guide, 1.1mm x 10°	KURGE
CoCr PALS-30300-CC (01)00841506107134 <b>3.0mm</b> K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152	(01) 00841506107134	PLS AIMing Guide, 1.1mm x 10° PDG-AIM-011	
CoCr PALS-30300-CC (01)00841506107134 <b>3.0mm</b> K-Wire, Standard Tip, 1.1 mm x 152 mm	(01) 00841506107134 Polyaxial Lockin	PLS AIMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625	(01) 00841506106625
CoCr PALS-30300-CC (01)00841506107134 K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152	(01) 00841506107134 Polyaxial Lockin	PLS AIMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625	(01) 00841506106625
CoCr PALS-30300-CC (01)00841506107134 K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 (01) 00841506106632 2.5mm Polyaxia	PLS AIMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 Il Locking Screws	
CoCr PALS-30300-CC (01)00841506107134 K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632 Screw, Polyaxial Locking, 2.5mm x 10mm	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 (01) 00841506106632 2.5mm Polyaxia	PLS AlMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 Il Locking Screws Screw, Polyaxial Locking, 2.5mm x 22mm	
CoCr PALS-30300-CC (01)00841506107134 K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632 Screw, Polyaxial Locking, 2.5mm x 10mm CoCr	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 (01) 00841506106632 2.5mm Polyaxia	PLS AlMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 Al Locking Screws Screw, Polyaxial Locking, 2.5mm x 22mm CoCr	
CoCr PALS-30300-CC (01)00841506107134 K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632 Screw, Polyaxial Locking, 2.5mm x 10mm CoCr PALS-25100-CC	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 2.5mm Polyaxia Cannulated,	PLS AlMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 Al Locking Screws Screw, Polyaxial Locking, 2.5mm x 22mm CoCr PALS-25220-CC	Cannulated,
CoCr PALS-30300-CC (01)00841506107134 <b>3.0mm</b> K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632 Screw, Polyaxial Locking, 2.5mm x 10mm CoCr PALS-25100-CC (01)00841506102665	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 2.5mm Polyaxia Cannulated, (01) 00841506102665	PLS AIMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 I Locking Screws Screw, Polyaxial Locking, 2.5mm x 22mm CoCr PALS-25220-CC (01)00841506102726	Cannulated,
CoCr PALS-30300-CC (01)00841506107134 K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632 Screw, Polyaxial Locking, 2.5mm x 10mm CoCr PALS-25100-CC (01)00841506102665 Screw, Polyaxial Locking, 2.5mm x 12mm	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 2.5mm Polyaxia Cannulated, (01) 00841506102665	PLS AlMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 I Locking Screws Screw, Polyaxial Locking, 2.5mm x 22mm CoCr PALS-25220-CC (01)00841506102726 Screw, Polyaxial Locking, 2.5mm x 24mm	Cannulated,
CoCr PALS-30300-CC (01)00841506107134 K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632 Screw, Polyaxial Locking, 2.5mm x 10mm CoCr PALS-25100-CC (01)00841506102665 Screw, Polyaxial Locking, 2.5mm x 12mm CoCr	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 2.5mm Polyaxia Cannulated, (01) 00841506102665	PLS AlMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 I Locking Screws Screw, Polyaxial Locking, 2.5mm x 22mm CoCr PALS-25220-CC (01)00841506102726 Screw, Polyaxial Locking, 2.5mm x 24mm CoCr	Cannulated,
CoCr PALS-30300-CC (01)00841506107134 K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632 Screw, Polyaxial Locking, 2.5mm x 10mm CoCr PALS-25100-CC (01)00841506102665 Screw, Polyaxial Locking, 2.5mm x 12mm CoCr PALS-25120-CC	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 2.5mm Polyaxia Cannulated, (01) 00841506102665 Cannulated,	PLS AlMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 I Locking Screws Screw, Polyaxial Locking, 2.5mm x 22mm CoCr PALS-25220-CC (01)00841506102726 Screw, Polyaxial Locking, 2.5mm x 24mm CoCr PALS-25240-CC	Cannulated, (01) 00841506102726 Cannulated,
CoCr PALS-30300-CC (01)00841506107134 K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632 Screw, Polyaxial Locking, 2.5mm x 10mm CoCr PALS-25100-CC (01)00841506102665 Screw, Polyaxial Locking, 2.5mm x 12mm CoCr PALS-25120-CC (01)00841506102672	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 2.5mm Polyaxia Cannulated, (01) 00841506102665 Cannulated, (01) 00841506102672	PLS AlMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 <b>I Locking Screws</b> Screw, Polyaxial Locking, 2.5mm x 22mm CoCr PALS-25220-CC (01)00841506102726 Screw, Polyaxial Locking, 2.5mm x 24mm CoCr PALS-25240-CC (01)00841506102733	Cannulated, (01) 00841506102726 Cannulated, (01) 00841506102733
CoCr PALS-30300-CC (01)00841506107134 K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632 Screw, Polyaxial Locking, 2.5mm x 10mm CoCr PALS-25100-CC (01)00841506102665 Screw, Polyaxial Locking, 2.5mm x 12mm CoCr PALS-25120-CC (01)00841506102672 Screw, Polyaxial Locking, 2.5mm x 14mm	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 2.5mm Polyaxia Cannulated, (01) 00841506102665 Cannulated, (01) 00841506102672	PLS AlMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 <b>I Locking Screws</b> Screw, Polyaxial Locking, 2.5mm x 22mm CoCr PALS-25220-CC (01)00841506102726 Screw, Polyaxial Locking, 2.5mm x 24mm CoCr PALS-25240-CC (01)00841506102733 Screw, Polyaxial Locking, 2.5mm x 26mm	Cannulated, (01) 00841506102726 Cannulated, (01) 00841506102733
CoCr PALS-30300-CC (01)00841506107134 K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632 Screw, Polyaxial Locking, 2.5mm x 10mm CoCr PALS-25100-CC (01)00841506102665 Screw, Polyaxial Locking, 2.5mm x 12mm CoCr PALS-25120-CC (01)00841506102672 Screw, Polyaxial Locking, 2.5mm x 14mm CoCr	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 2.5mm Polyaxia Cannulated, (01) 00841506102665 Cannulated, (01) 00841506102672	PLS AlMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 <b>I Locking Screws</b> Screw, Polyaxial Locking, 2.5mm x 22mm CoCr PALS-25220-CC (01)00841506102726 Screw, Polyaxial Locking, 2.5mm x 24mm CoCr PALS-25240-CC (01)00841506102733 Screw, Polyaxial Locking, 2.5mm x 26mm CoCr	Cannulated, (01) 00841506102726 Cannulated, (01) 00841506102733
CoCr PALS-30300-CC (01)00841506107134 K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632 Screw, Polyaxial Locking, 2.5mm x 10mm CoCr PALS-25100-CC (01)00841506102665 Screw, Polyaxial Locking, 2.5mm x 12mm CoCr PALS-25120-CC (01)00841506102672 Screw, Polyaxial Locking, 2.5mm x 14mm CoCr PALS-25140-CC	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 2.5mm Polyaxia Cannulated, (01) 00841506102665 Cannulated, (01) 00841506102672 Cannulated,	PLS AlMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 <b>I Locking Screws</b> Screw, Polyaxial Locking, 2.5mm x 22mm CoCr PALS-25220-CC (01)00841506102726 Screw, Polyaxial Locking, 2.5mm x 24mm CoCr PALS-25240-CC (01)00841506102733 Screw, Polyaxial Locking, 2.5mm x 26mm CoCr PALS-25260-CC	Cannulated, (01) 00841506102726 Cannulated, (01) 00841506102733 Cannulated,
CoCr PALS-30300-CC (01)00841506107134 K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632 Screw, Polyaxial Locking, 2.5mm x 10mm CoCr PALS-25100-CC (01)00841506102665 Screw, Polyaxial Locking, 2.5mm x 12mm CoCr PALS-25120-CC (01)00841506102672 Screw, Polyaxial Locking, 2.5mm x 14mm CoCr PALS-25140-CC (01)00841506102689	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 2.5mm Polyaxia Cannulated, (01) 00841506102665 Cannulated, (01) 00841506102672 Cannulated, (01) 00841506102672	PLS AlMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 <b>I Locking Screws</b> Screw, Polyaxial Locking, 2.5mm x 22mm CoCr PALS-25220-CC (01)00841506102726 Screw, Polyaxial Locking, 2.5mm x 24mm CoCr PALS-25240-CC (01)00841506102733 Screw, Polyaxial Locking, 2.5mm x 26mm CoCr PALS-25260-CC (01)00841506102740	Cannulated, (01) 00841506102726 Cannulated, (01) 00841506102733 Cannulated,
CoCr PALS-30300-CC (01)00841506107134 K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632 Screw, Polyaxial Locking, 2.5mm x 10mm CoCr PALS-25100-CC (01)00841506102665 Screw, Polyaxial Locking, 2.5mm x 12mm CoCr PALS-25120-CC (01)00841506102672 Screw, Polyaxial Locking, 2.5mm x 14mm CoCr PALS-25140-CC (01)00841506102689 Screw, Polyaxial Locking, 2.5mm x 16mm	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 2.5mm Polyaxia Cannulated, (01) 00841506102665 Cannulated, (01) 00841506102672 Cannulated, (01) 00841506102672	PLS AlMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 <b>I Locking Screws</b> Screw, Polyaxial Locking, 2.5mm x 22mm CoCr PALS-25220-CC (01)00841506102726 Screw, Polyaxial Locking, 2.5mm x 24mm CoCr PALS-25240-CC (01)00841506102733 Screw, Polyaxial Locking, 2.5mm x 26mm CoCr PALS-25260-CC (01)00841506102740 Screw, Polyaxial Locking, 2.5mm x 28mm	Cannulated, (01) 00841506102726 Cannulated, (01) 00841506102733 Cannulated,
CoCr PALS-30300-CC (01)00841506107134 K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632 Screw, Polyaxial Locking, 2.5mm x 10mm CoCr PALS-25100-CC (01)00841506102665 Screw, Polyaxial Locking, 2.5mm x 12mm CoCr PALS-25120-CC (01)00841506102672 Screw, Polyaxial Locking, 2.5mm x 14mm CoCr PALS-25140-CC (01)00841506102689 Screw, Polyaxial Locking, 2.5mm x 16mm CoCr	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 2.5mm Polyaxia Cannulated, (01) 00841506102665 Cannulated, (01) 00841506102672 Cannulated, (01) 00841506102672	PLS AlMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 <b>I Locking Screws</b> Screw, Polyaxial Locking, 2.5mm x 22mm CoCr PALS-25220-CC (01)00841506102726 Screw, Polyaxial Locking, 2.5mm x 24mm CoCr PALS-25240-CC (01)00841506102733 Screw, Polyaxial Locking, 2.5mm x 26mm CoCr PALS-25260-CC (01)00841506102740 Screw, Polyaxial Locking, 2.5mm x 28mm CoCr	Cannulated, (01) 00841506102726 Cannulated, (01) 00841506102733 Cannulated,
CoCr PALS-30300-CC (01)00841506107134 K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632 Screw, Polyaxial Locking, 2.5mm x 10mm CoCr PALS-25100-CC (01)00841506102665 Screw, Polyaxial Locking, 2.5mm x 12mm CoCr PALS-25120-CC (01)00841506102672 Screw, Polyaxial Locking, 2.5mm x 14mm CoCr PALS-25140-CC (01)00841506102689 Screw, Polyaxial Locking, 2.5mm x 16mm CoCr PALS-25160-CC	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 2.5mm Polyaxia Cannulated, (01) 00841506102665 Cannulated, (01) 00841506102672 Cannulated, (01) 00841506102689 Cannulated,	PLS AlMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 <b>Il Locking Screws</b> Screw, Polyaxial Locking, 2.5mm x 22mm CoCr PALS-25220-CC (01)00841506102726 Screw, Polyaxial Locking, 2.5mm x 24mm CoCr PALS-25240-CC (01)00841506102733 Screw, Polyaxial Locking, 2.5mm x 26mm CoCr PALS-25260-CC (01)00841506102740 Screw, Polyaxial Locking, 2.5mm x 28mm CoCr PALS-25280-CC	Cannulated, (01) 00841506102726 Cannulated, (01) 00841506102733 Cannulated, (01) 00841506102740 Cannulated,
CoCr PALS-30300-CC (01)00841506107134 <b>3.0mm</b> K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632 <b>Screw</b> , Polyaxial Locking, 2.5mm x 10mm CoCr PALS-25100-CC (01)00841506102665 Screw, Polyaxial Locking, 2.5mm x 12mm CoCr PALS-25120-CC (01)00841506102672 Screw, Polyaxial Locking, 2.5mm x 14mm CoCr PALS-25140-CC (01)00841506102689 Screw, Polyaxial Locking, 2.5mm x 16mm CoCr PALS-25160-CC (01)00841506102696	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 2.5mm Polyaxia Cannulated, (01) 00841506102665 Cannulated, (01) 00841506102672 Cannulated, (01) 00841506102689 Cannulated, (01) 00841506102689	PLS AlMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 <b>I Locking Screws</b> Screw, Polyaxial Locking, 2.5mm x 22mm CoCr PALS-25220-CC (01)00841506102726 Screw, Polyaxial Locking, 2.5mm x 24mm CoCr PALS-25240-CC (01)00841506102733 Screw, Polyaxial Locking, 2.5mm x 26mm CoCr PALS-25260-CC (01)00841506102740 Screw, Polyaxial Locking, 2.5mm x 28mm CoCr PALS-25280-CC (01)00841506102757	Cannulated, (01) 00841506102726 Cannulated, (01) 00841506102733 Cannulated, (01) 00841506102740 Cannulated,
CoCr PALS-30300-CC (01)00841506107134 K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632 Screw, Polyaxial Locking, 2.5mm x 10mm CoCr PALS-25100-CC (01)00841506102665 Screw, Polyaxial Locking, 2.5mm x 12mm CoCr PALS-25120-CC (01)00841506102672 Screw, Polyaxial Locking, 2.5mm x 14mm CoCr PALS-25140-CC (01)00841506102689 Screw, Polyaxial Locking, 2.5mm x 16mm CoCr PALS-25160-CC (01)00841506102696 Screw, Polyaxial Locking, 2.5mm x 18mm	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 2.5mm Polyaxia Cannulated, (01) 00841506102665 Cannulated, (01) 00841506102672 Cannulated, (01) 00841506102689 Cannulated, (01) 00841506102689	PLS AlMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 <b>I Locking Screws</b> Screw, Polyaxial Locking, 2.5mm x 22mm CoCr PALS-25220-CC (01)00841506102726 Screw, Polyaxial Locking, 2.5mm x 24mm CoCr PALS-25240-CC (01)00841506102733 Screw, Polyaxial Locking, 2.5mm x 26mm CoCr PALS-25260-CC (01)00841506102740 Screw, Polyaxial Locking, 2.5mm x 28mm CoCr PALS-25280-CC (01)00841506102757 Screw, Polyaxial Locking, 2.5mm x 30mm	Cannulated, (01) 00841506102726 Cannulated, (01) 00841506102733 Cannulated, (01) 00841506102740 Cannulated,
CoCr PALS-30300-CC (01)00841506107134 K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632 Screw, Polyaxial Locking, 2.5mm x 10mm CoCr PALS-25100-CC (01)00841506102665 Screw, Polyaxial Locking, 2.5mm x 12mm CoCr PALS-25120-CC (01)00841506102672 Screw, Polyaxial Locking, 2.5mm x 14mm CoCr PALS-25140-CC (01)00841506102689 Screw, Polyaxial Locking, 2.5mm x 16mm CoCr PALS-25160-CC (01)00841506102696 Screw, Polyaxial Locking, 2.5mm x 16mm CoCr	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 2.5mm Polyaxia Cannulated, (01) 00841506102665 Cannulated, (01) 00841506102672 Cannulated, (01) 00841506102689 Cannulated, (01) 00841506102689	PLS AlMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 <b>I Locking Screws</b> Screw, Polyaxial Locking, 2.5mm x 22mm CoCr PALS-25220-CC (01)00841506102726 Screw, Polyaxial Locking, 2.5mm x 24mm CoCr PALS-25240-CC (01)00841506102733 Screw, Polyaxial Locking, 2.5mm x 26mm CoCr PALS-25260-CC (01)00841506102740 Screw, Polyaxial Locking, 2.5mm x 28mm CoCr PALS-25280-CC (01)00841506102757 Screw, Polyaxial Locking, 2.5mm x 30mm CoCr	Cannulated, (01) 00841506102726 Cannulated, (01) 00841506102733 Cannulated, (01) 00841506102740 Cannulated,
CoCr PALS-30300-CC (01)00841506107134 K-Wire, Standard Tip, 1.1 mm x 152 mm KWIR-PLS-11152 (01)00841506106632 Screw, Polyaxial Locking, 2.5mm x 10mm CoCr PALS-25100-CC (01)00841506102665 Screw, Polyaxial Locking, 2.5mm x 12mm CoCr PALS-25120-CC (01)00841506102672 Screw, Polyaxial Locking, 2.5mm x 14mm CoCr PALS-25140-CC (01)00841506102689 Screw, Polyaxial Locking, 2.5mm x 16mm CoCr PALS-25160-CC (01)00841506102696 Screw, Polyaxial Locking, 2.5mm x 18mm	(01) 00841506107134 Polyaxial Lockin (01) 00841506106632 2.5mm Polyaxia Cannulated, (01) 00841506102665 Cannulated, (01) 00841506102672 Cannulated, (01) 00841506102689 Cannulated, (01) 00841506102689	PLS AlMing Guide, 1.1mm x 10° PDG-AIM-011 (01)00841506106625 <b>I Locking Screws</b> Screw, Polyaxial Locking, 2.5mm x 22mm CoCr PALS-25220-CC (01)00841506102726 Screw, Polyaxial Locking, 2.5mm x 24mm CoCr PALS-25240-CC (01)00841506102733 Screw, Polyaxial Locking, 2.5mm x 26mm CoCr PALS-25260-CC (01)00841506102740 Screw, Polyaxial Locking, 2.5mm x 28mm CoCr PALS-25280-CC (01)00841506102757 Screw, Polyaxial Locking, 2.5mm x 30mm	Cannulated, (01) 00841506102726 Cannulated, (01) 00841506102733 Cannulated, (01) 00841506102740 Cannulated,

Screw, Polyaxial Locking, 2.5mm x 20m	m Cannulated,				
CoCr	144				
PALS-25200-CC	<u>16756</u>				
(01)00841506102719	(01)00841506102719				
2.5mm Polyaxial Locking Screw Instrumentation					
K-Wire, Standard Tip, .9mm x 152mm		PLS AIMing Guides			
KWIR-STD-09152		PLS-AIM-0910			
(01)00841506102498	<u>- 68</u>	(01)00841506102887	en a transmission La maria		
	(01)00841506102498		(01)00841506102887		

	ALIGN Radial	Head Implants	
Radial Head, 18mm ALN-RHI-180 (01)00841506100012	(01) 00841506100012	Stem, 9mm x 0mm ALN-RST-0900 (01)00841506100166	(01) 00841506100166
Radial Head, 20mm ALN-RHI-200 (01)00841506100029	(01) 00841506100029	Stem, 9mm x 2mm ALN-RST-0902 (01)00841506100173	(01) 00841506100173
Radial Head, 22mm ALN-RHI-220 (01)00841506100036	(01) 00841506100036	Stem, 9mm x 4mm ALN-RST-0904 (01)00841506100180	(01) 00841506100180
Radial Head, 24mm ALN-RHI-240 (01)00841506100043	(01) 00841506100043	Stem, 9mm x 6mm ALN-RST-0906 (01)00841506100197	(01) 00841506100197
Radial Head, 26mm ALN-RHI-260 (01)00841506100050	(01) 00841506100050	Stem, 9mm x 8mm ALN-RST-0908 (01)00841506100203	(01) 00841506100203
Radial Head, 28mm ALN-RHI-280 (01)00841506131542	(01) 00841506131542	Stem, 10mm x 0mm ALN-RST-1000 (01)00841506100210	(01) 00841506100210
Stem, 6mm x 0mm ALN-RST-0600 (01)00841506131702	(01) 00841506131702	Stem, 10mm x 2mm ALN-RST-1002 (01)00841506100227	(01) 00841506100227
Stem, 6mm x 2mm ALN-RST-0602 (01)00841506131719	(01) 00841506131719	Stem, 10mm x 4mm ALN-RST-1004 (01)00841506100234	(01) 00841506100234
Stem, 6mm x 4mm ALN-RST-0604 (01)00841506131726	(01) 00841506131726	Stem, 10mm x 6mm ALN-RST-1006 (01)00841506100241	(01) 00841506100241
Stem, 6mm x 6mm ALN-RST-0606 (01)00841506131733	(01) 00841506131733	Stem, 10mm x 8mm ALN-RST-1008 (01)00841506100258	(01) 00841506100258
Stem, 6mm x 8mm ALN-RST-0608 (01)00841506131740	(01) 00841506131740	Stem, 11mm x 0mm ALN-RST-1100 (01)00841506100265	(01) 00841506100265
Stem, 7mm x 0mm ALN-RST-0700 (01)00841506100067	(01) 00841506100067	Stem, 11mm x 2mm ALN-RST-1102 (01)00841506100272	(01) 00841506100289
Stem, 7mm x 2mm ALN-RST-0702 (01)00841506100074	(01) 00841506100074	Stem, 11mm x 4mm ALN-RST-1104 (01)00841506100289	(01) 00841506100289

Stem, 7mm x 4mm ALN-RST-0704 (01)00841506100081	(01) 00841506100081	Stem, 11mm x 6mm ALN-RST-1106 (01)00841506100296	(01) 00841506100296
Stem, 7mm x 6mm ALN-RST-0706 (01)00841506100098	(01) 00841506100098	Stem, 11mm x 8mm ALN-RST-1108 (01)00841506100302	(01) 00841506100302
Stem, 7mm x 8mm ALN-RST-0708 (01)00841506100104	(01) 00841506100104	Stem, 12mm x 0mm ALN-RST-1200 (01)00841506131603	(01) 00841506131603
Stem, 8mm x 0mm ALN-RST-0800 (01)00841506100111	(01) 00841506100111	Stem, 12mm x 2mm ALN-RST-1202 (01)00841506131610	(01) 00841506131610
Stem, 8mm x 2mm ALN-RST-0802 (01)00841506100128	(01) 00841506100128	Stem, 12mm x 4mm ALN-RST-1204 (01)00841506131627	(01) 00841506131627
Stem, 8mm x 4mm ALN-RST-0804 (01)00841506100135	(01) 00841506100135	Stem, 12mm x 6mm ALN-RST-1206 (01)00841506131634	(01) 00841506131634
Stem, 8mm x 6mm ALN-RST-0806 (01)00841506100142	(01) 00841506100142	Stem, 12mm x 8mm ALN-RST-1208 (01)00841506131641	(01) 00841506131641
Stem, 8mm x 8mm ALN-RST-0808 (01)00841506100159	(01) 00841506100159		